



Quick Start Guide



MASTER POWER STATION

Standard Edition / Tai Chi Edition

Table of Contents

Overview	1
Key Features	2
Safety Precautions	3
Product Recycling	3
Packaging Contents	4
Installation Location	4
Operating Instructions	4
Wiring Diagram	5
System Diagram	5
Dimension Diagram	6
Equipment Specifications	7

Overview

"Power Resonator", for use in electronic and communication systems, reduces high-frequency harmonic noise in the power. It utilizes a chip with frequency-dividing capabilities to capture harmonic interference sources in the power, continuously dividing the interference frequency to reduce its harmonic interference.

In audio system, you can noticeably experience an enhancement in spatial sound, which means that music or sound becomes more realistic, three-dimensional, and natural, providing a rich and clear audio experience.

Master Power Station

Telos "Master Power Station" is an outstanding "power resonator" inspired by the design of electronic clocks popular before the 1970s. In those times, electronic clocks often used the 60Hz frequency from the mains power as their base frequency, and we discovered that this design had subtle yet magical effects on audio systems. Therefore, we based the development of Telos's unique tuning product on this core concept.

This product is used similarly to a standard filtering power strip, directly connected in parallel to the power circuit of your audio system, but without internal components like series coils. Through its built-in frequency-dividing chip, it continuously divides the interference frequency eight times. By simply paralleling the "Master Power Station" to your audio system's power circuit, you can experience its effects.

This design enhances the performance of your audio system, allowing you to distinctly perceive higher audio quality and a deeper appreciation of its subtle nuances. Telos "Master Power Station" represents our commitment to providing exceptional quality to audio enthusiasts, and we will continue to strive for innovation to meet the pursuit of high-quality audio experiences.



Key Features

Multi-Channel Outputs:

Telos "Master Power Station" offers 8 independent output channels, allowing simultaneous processing of multiple power supplies, providing greater flexibility and versatility.

Material Technology :

With 11 material options, it can effectively adapt to various environments and applications, ensuring maximum energy utilization and transfer efficiency.

Easy Installation :

Designed for simplicity, it is easy to install and integrate into various applications without the need for complex setup processes.

Safety Precautions



Warning Symbol: Users should be aware that there is a non-insulated hazardous voltage within the equipment's outer casing, which may result in electric shock.



Caution Symbol: Users should take note that important operational, maintenance, and repair information is included in the user manual and maintenance manual.

- To reduce the risk of electric shock, do not remove the outer casing.
- There are no user-serviceable parts inside the equipment.
- Please leave maintenance tasks to qualified service personnel.
- When replacing the main fuse in the plug, use a fuse of the same type and rating.
- Before replacing the fuse, unplug the power cord.

Warning: To reduce the risk of fire or electric shock, do not expose the equipment to rain or damp environments. It carries a risk of electric shock; do not open it.

Product Recycling

This product is designed in compliance with international directives on the restriction of hazardous substances. (EX: Trash Bin Symbol) indicates compliance and requires these products to be recycled or disposed of in accordance with these directives.

Packaging Contents

- "Master Power Station" Main Unit
- Power Cable (2.56 meters) with Plugs for UK, EU, US, AU (Compatible with 8 outlets on the main unit)

Installation Location


Typically, you should place your main unit near your audio equipment and system rack for closer proximity to the connections of your audio equipment. The use of any type of power conditioner may lead to the main unit not functioning correctly. Telos does not recommend the use of any type of power conditioning device as the power source for the main unit.

Operating Instructions

Plug the power cord directly into a wall outlet.

Connect the power supply of your audio equipment to the main unit.

Wiring Diagram



① ② ③ ④ ⑥ ⑦ ⑧ ⑨

AC power output

⑤

AC power input

System Diagram

① ② ③ ④ ⑥ ⑦ ⑧ ⑨

8 Output Channels: 100-240V / 50-60Hz (Dependent on input power)


You can connect various components of your audio system to these channels, such as DAC, amplifier, preamp, and power amp.

⑤

Power Input: 100-240V / 50-60Hz

Connect the power input to your household outlet.

Dimension Diagram



Equipment Specifications

- Unit Dimensions (Bare): 48.5 x 38.5 x 24.5 cm
- Unit Dimensions (Packaged): 63 x 55 x 39 cm
- Unit Weight (Bare): 48 kg
- Unit Weight (Packaged): 68 kg
- 8 Output Channel Voltage: 100–240V / 50–60Hz (Dependent on input power)
- Input Power Voltage: 100–240V / 50–60Hz
- Maximum Current: 15A
- Full Load Output Power: 1800W
- Standby Power Consumption: 6W



Trademark Attribution Notice

Windows is a trademark or registered trademarks of Microsoft Corporation in the United States and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries. Android is a trademark of Google LLC, registered in the U.S. and other countries. Mac and macOS are trademarks of Apple Inc., registered in the U.S. and other countries. Apple is a trademark of Apple Inc., registered in the U.S. and other countries.